

PULL-OUT OPERATION

To operate a Pull-out tarp system correctly, the following steps are to be taken.

1. Take the guide rope which is either resting in the bin or secured near the headboard, and walk the rope to the rear of the body.
2. Centre the rope on the tailgate and smoothly pull the tarp towards the rear of the body.
3. Continue pulling until the rear anchor tube sits within the shark fins at the rear of the body.
4. Keeping constant tension on the rope and secure it either through looping it around a second set of shark fins, or tying off at a point on the tailgate.
5. Then release tension to complete the operation.

PULL-OUT SAFETY PRECAUTIONS

When operating a Pull-out style system, the following precautions are required:

- Always operate the system from the rear of the body.
- Refrain from jerking/sudden movements to pull anchor free of the Shark Fins.
- Only use the rope to control the return to the housing, not the pull tube.
- Stand well clear of the sides of the body when unit is retracting.
- Apply constant tension on the rope till the tarp fully retracts.
- Be aware of the unit's high level of pretension (18 turns clockwise)
- Use the proprietary tool when adjusting spring tension

Failure to comply with these precautions can result in injury and/or damage to the pull-out assembly. For further information on operating and installation procedures, contact our sales team at sales@retractabletarps.com.au or call (07) 3889 8611.

