

PIVOT ARM SYSTEM ARM PLACEMENT



Notes:

- Standard kits include additional 60° arm elbows. These are provided as extras in the event the arm is modified for clearance when in the open position. Standard arm will be straight.
- When mounting pivot base plates, keyway on shaft must point down.

Reference Dimensions

- A. Tarp should finish 100 mm forward of tailgate hinge for clearance
- B. Reference line (**RED**) should be 50 mm up from lowest clear point on body. This represents midpoint of pivot pin bracket which is 100 mm tall.

